



Patch-bay Configurations

Jack #1: 16 ohm mono cab

Jack #2: 8 ohm top two speakers in mono only

Jack #3: 16 ohm top right speaker only

Jack #2 and #3: top speakers 16 ohms each in stereo

Jack #4: 8 ohm bottom two speakers in mono only

Jack #5: 16 ohm bottom right speaker only

Jack #4 and #5: bottom speakers 16 ohms each in stereo

Jack #2 and #4: 8 ohms top two speakers in mono, 8 ohms bottom two speakers in mono

Jack #4, #2 and #3: 8 ohms mono bottom speakers, 16 ohms each top stereo speakers for WDW

NOTE: To run stereo L&R only, you will need two separate amplifiers. Using the 2x 8 ohm jacks on the back of amp one, plug each into jacks #2 and #4. On amp two, again using the 2x 8 ohm jacks, plug each one into jacks #3 and #5. In essence, you're addressing the separate speaker chambers as if they were individual cabinets.